# **MAGNA3**

Safety instructions and other important information







be think innovate



# English (US) Safety instructions

#### Original safety instructions.

# CONTENTS

		гауе
1.	Symbols used in this document	2
2.	Туре кеу	3
3.	Pumped liquids	4
4.	Radio communication	4
5.	Installation	4
5.1	Changing the control box position	4
6.	Electrical connection	4
7.	Operation	5
8.	Communication	5
8.1	CIM modules	5
9.	Fault finding	5
10.	Technical data	5
10.1	Ambient temperature	5
10.2	Maximum system pressure	5
10.3	Approvals	5
11.	Further product information	5
12.	Disposal	5

#### Warning

Prior to installation. read this document and the Quick Guide. Installation and operation must comply with local regulations and accepted codes of good practice.

#### Warning

The use of this product requires experience with and knowledge of the product.



Persons with reduced physical, sensory or mental capabilities must not use this product, unless they are under supervision or have been instructed in the use of the product by a person responsible for their safety.

Children must not use or play with this product.

### 1. Symbols used in this document

#### Warning

If these safety instructions are not observed, it may result in personal injury.

#### Warning



If these safety instructions are not observed, it may lead to electric shock with consequent risk of serious personal injury or death.



#### Warning

The surface of the product may be so hot that it may cause burns or personal injury.



#### Warning



Risk of dropping objects which may cause personal injury.



#### Warning


Escaping vapor involves the risk of personal injury.



If these safety instructions are not observed, it may result in malfunction or damage to the



Notes or instructions that make the



# 2. Type key

<b>ange</b> A3 -head pump ead pump al diameter (DN) of suction	on and discharge p	oorts [m	) nm]				
ead pump	on and discharge p	oorts [m	] nm]				
al diameter (DN) of suction	on and discharge p	oorts [m	nm]				
um head [dm]				-			
on						-	
r	connection e housing material ron ess steel o-port length [mm]	e housing material ron ess steel					

# 3. Pumped liquids

The pump can be used for pumping water/glycol mixtures up to 50 %.

### Warning



Do not use the pump for flammable liquids, such as diesel oil and gasoline.

# 4. Radio communication

GRUNDFOS HOLDING A/S **RADIOMODULE 2G4** 

CONTAINS ECC ID: OG3-RADIOM01-2G4 CONTAINS IC: 10447A-RA2G4M01

This device complies with part 15 of the FCC Rules and RSS 2010 of IC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

#### Intended use

This product incorporates a radio for remote control.

Only Grundfos-approved external antennae may be connected to this product, and only by a Grundfos-approved installer.

# 5. Installation

### 5.1 Changing the control box position



#### Warning

Warning

Observe local regulations setting limits for manual lifting or handling.

Before dismantling the pump, drain

the system or close the isolating

valve on either side of the pump. The pumped liquid may be scalding hot and under high pressure.



# Warning

When loosening the clamp, do not drop the pump head.



Warning Risk of escaping vapor.

# 6 Electrical connection

Carry out the electrical connection and protection according to local regulations.

If rigid conduit is to be used, the hub must be connected to the conduit system before it is connected to the terminal box of the pump.



The protective earth (ground) symbol identifies any terminal which is intended for connection to an external conductor for protection against electrical shock in case of a

fault, or the terminal of a protective earth (ground) electrode.



#### Warning

Switch off the power supply before making connections.

#### Warning

The pump must be connected to an external mains switch with a minimum contact gap of 0.12 inches (3 mm) in all poles. Grounding or neutralization must be used for protection against indirect contact.



If the pump is connected to an electric installation where a Ground Fault Circuit Interrupter (GFCI) is used as an additional protection, this circuit interrupter must trip when ground fault currents with DC content (pulsating DC) occur. The ground fault circuit interrupter

must be marked with the first or both of the symbols shown below:



#### Warning



It must be possible to lock the mains switch in position 0. Type and requirements as specified in EN 60204-1, 5.3.2.

# 7. Operation

#### Warning

At high liquid temperatures, the pump may be very hot. In that case only touch the button.

The surface of the pump may be so hot that it may cause burns or personal injury.

## 8. Communication

#### 8.1 CIM modules

8.1.1 Fitting the CIM module

#### Warning



Before fitting the module, switch off the power supply. Make sure that the power supply cannot be accidentally switched on.

# 9. Fault finding

#### Warning



Before dismantling the pump or related parts, drain the system and close the isolating valves on both sides of the pump as the pumped liquid may be scalding hot and under high pressure.

#### Warning



If the power supply cable is damaged, it must be replaced by the manufacturer, the manufacturer's service partner or a similarly qualified person.

# 10. Technical data

#### 10.1 Ambient temperature

+32 to +104 °F (0 to +40 °C).

#### 10.2 Maximum system pressure

The maximum system pressure is indicated on the nameplate:

175 psi (12 bar).

### 10.3 Approvals

Conforms to ANSI/UL Standard 778. Certified to CAN/CSA Standard C22.2 No. 108.

# **11. Further product information**



GRUNDFOS.COM/MANUAL-MAGNA3

# 12. Disposal

This product has been designed with a focus on the disposal and recycling of materials. The following average disposal values apply to all variants of Grundfos MAGNA3 pumps:

- 85 % recycling
- 10 % incineration
- 5 % depositing.

This product or parts of it must be disposed of in an environmentally sound way according to local regulations.

Subject to alterations.

#### **GRUNDFOS Kansas City**

17100 West 118th Terrace Olathe, Kansas 66061 Phone: (913) 227-3400 Fax: (913) 227-3500

www.grundfos.us

#### **GRUNDFOS** Canada

2941 Brighton Road Oakville, Ontario L6H 6C9 Canada Phone: +1-905 829 9533 Telefax: +1-905 829 9512

www.grundfos.ca

#### **GRUNDFOS México**

Boulevard TLC No. 15 Parque Industrial Stiva Aeropuerto C.P. 66600 Apodaca, N.L. México Phone: 011-52-81-8144 4000 Fax: 011-52-81-8144 4010

www.grundfos.mx

© Copyright Grundfos Holding A/S

The name Grundros, the Grundros logo, and **be think innovate** are registered trademarks owned by Grundros Holding A/S or Grundros A/S, Denmark. All rights reserved worldwide.

L-MAG-TL-11

98385930 0813

ECM: 1119936



www.grundfos.com